



# Wilo-IF-Modul Stratos CAN

**Fig. 1**

- Ⓧ Einbau- und Betriebsanleitung
- Ⓧ Installation and operating instructions
- Ⓧ Notice de montage et de mise en service
- Ⓧ Inbouw- en bedieningsvoorschriften
- Ⓧ Instrucciones de instalación y funcionamiento
- Ⓧ Istruzioni di montaggio, uso e manutenzione
- Ⓧ Asennus- ja käyttöohje
- Ⓧ Monterings- och skötselanvisning
- Ⓧ Beépítési és üzemeltetési utasítás
- Ⓧ Οδηγίες εγκατάστασης και λειτουργίας
- Ⓧ Návod k montáži a obsluze
- Ⓧ Instrukcja montażu i obsługi
- Ⓧ Инструкция по монтажу и эксплуатации
- Ⓧ Monterings- og driftsvejledning
- Ⓧ Montasje- og bruksanvisning



[www.wilo.com/automation](http://www.wilo.com/automation)

**Fig. 2**

2 066 600

**Fig. 3**

Wilo-Stratos/Stratos-Z

+ 1 x Wilo-IF-Modul Stratos CAN (Art.-Nr. 2 066 600)

**Fig. 4**

Wilo-Stratos-D

+ 1 x Wilo-IF-Modul Stratos CAN (Art.-Nr. 2 066 600)  
+ 1 x Wilo-IF-Modul Stratos DP (Art.-Nr. 2 105 254)



# Wilo-IF-Modul Stratos CAN

Fig. 5




Fig. 6

